

ref.: 00618




**descarga interrumpible ECOSTOP U1**

press & stop flush mechanism ECOSTOP U1

mécanisme interrompable ECOSTOP U1

autoclismo interruptível ECOSTOP U1

batteria scarico interrompibile ECOSTOP U1




**ahorro agua**  
water saver  
économiseur d'eau  
poupador de água  
risparmio d'acqua  
wassersparend




**base roscada**  
threaded base  
base fileté  
base roscada  
base filettata  
gewinde-basis



cromo / chrome / chromé / cromo / cromato  
caja imp. / pri. box / boîte imp. / caixa imp. / scat. stam.  
ABS / INOX / POM



start & stop



plastisan®  
©2016/11/03

